

WASHLET GL

TOTO

MAIN KEYS (COVER CLOSED)

Stop

Stops washing

Rear

Starts rear cleansing

Front

Starts bidet cleansing

Oscillating

Moves the wand back and forth for thorough cleansing

Power Deodorizer

Purifies the air inside the bowl through a powerful filter

Pressure

Adjusts the WASHLET's water pressure

Position

Adjusts the water flow position

SUB KEYS (COVER OPEN)

Energy Saver timer

Activates the energy saving mode with settings of 3, 6 or 9 hours

Wand cleaning

Extends the wand for manual cleaning

Water temperature

Adjusts the water temperature

Seat temperature

Adjusts the temperature of the WASHLET's seat