INSTALLATION GUIDE

тото

FLOTATION TUB WITH RECLINE COMFORT



- Cautions and warnings ······2
- Included parts ······ 5
- Required tools ······ 6
- Specifications ······7
- Dimension drawings ······ 8
- Installing the bathtub ………10
- Finishing15

To service installers

Please explain the FLOTATION TUB functions and operation to the customers.

Cautions and warnings

Please read the installation manual and follow these cautions and warnings carefully before beginning the construction.

Follow all safety precautions and warnings.

| When this appears next to a topic, this indicates that misoperation could result in death or serious injury. |
|--|
| When this appears next to a topic, this indicates that misoperation may result in injury or physical damage. |

• The following symbols are used to classify and explain instructions that must be followed.

| Symbol example | Meaning of symbol |
|----------------|---|
| \bigcirc | This symbol indicates something that is "Prohibited". |
| 0 | This symbol indicates something that is "Required". |

| \bigcirc | Do not stand on bathtub while working.Doing so could cause a fall or injury or damage the components. |
|----------------------------|--|
| Prohibited | Only install the supplied parts or directed parts, and do not apply any changes to them. Especially make sure not to change the dimensions of the product. |
| | Make sure to follow the installation guide for installation. • Incomplete installation can result in a fire or electric shock. Otherwise, there is a chance of leakage that could wet and cause damage to household property. |
| Q Always observe | Make sure to follow the procedures for the drainage piping attachment. Defective construction can result in water leakage that could wet and cause damage to household property. |
| | After unpacking, swiftly dispose of any unnecessary packing materials. • The wood frame, nails, cardboard boxes, vinyl bags, or sealing straps may cause an injury. If children play with the packaging materials there is a risk of suffocation or other accidents. |

| | Attach the tap water supply equipment to the bathtub. |
|----------------------------|--|
| O Always observe | Make sure to install the bathtub according to the installation guide and in a stable location that can withstand its mass. Defective installation can result in an injury caused by the bathtub falling or flipping over. |
| | Ensure that you have an ergonomic working position during transport and assembly Take care at every stage that your move is safe. Ensure that you have assistance to avoid risk of accident or injury. |
| | Observe the current local prevention of accidents and building regulations as well a sanitary and environmental protection rules during installation. |
| aways observe | Stabilise the bathtub with a fixing plate.The bathtub may shake if it is not properly stabilised. |
| | Secure enough space between the bathtub and tiles, and fill that space with silicone that does not contain alcohol. |
| | Check to see that the hole positions are not overlapping with the cavity portions of the tile base. |
| | • If there are cavities, use an adhesive anchor to stabilise. |

| | Do not place a stepladder inside the bathtub or place heavy objects on the edge the bathtub. • This may cause damage. |
|----------------|---|
| | Do not drop or bump anything hard or heavy onto the bathtub. This may cause the bathtub to crack and result in an injury, or leakage that could wet and cause damage to household property. |
| Prohibited | Keep sources of heat at a distance. Do not smoke.Doing so could cause damage. |
| | Do not install the bathtub outdoors or in a location that is regularly exposed to sunlight (such as a sun room). • This may cause the bathtub to freeze and cause damage or discoloration. |
| | When delivering the bathtub, do not hold the hose or piping or bump anything hard against it. |
| | When opening the packaging, make sure that all of the supplied parts and the bathtub itself are not damaged, and if they are, do not use the damaged parts. • Replace any damaged parts. |
| | When installing the bathtub in a location that could result in damage due to water leakage, make sure to apple waterproof processing construction on the floor surface • If there is water leakage, it may cause damage to the floor below. |
| Always observe | Remove the bathtub's protective sheet after the construction is completed. |
| - | Secure an area that enables proper space for the usage and maintenance of the bathtu |
| | Before completing the installation, make sure to confirm the sealability of each part • If water leakage is detected, remove the cause of the leakage. |
| | Please conduct site operation directly on the drain. |

Included parts



Required tools



Specifications

| Item | Specifi | cations |
|---------------------|---------------------------------------|---------------------------------------|
| Product Number | PJY1724 | PJY1744 |
| External dimensions | 1700 mm (L) × 800 mm (W) × 565 mm (H) | 1700 mm (L) × 835 mm (W) × 565 mm (H) |
| Bathtub depth | 450 | mm |
| Capacity | 255 L | 229L |
| Weight | 96.4 kg | 96.8 kg |
| Materials | Artificial marble made of (| GFRP sandwich structure. |
| Drainage method | Normal drainage + | Overflow drainage |
| Drain plug | Push-operat | ed drain plug |
| Drainage rate | 55 L | /min |
| Overflow rate | 36 L | /min |

Dimension drawings

PJY1724HPW















Installation procedures for GALALINE







4 \odot >>P.10







7

8 ×۵ ۵



>>P.11

>>P.10





*The design of the figure is different from the actual product.





9

Installing the bathtub for GALALINE















Conduct a fill water

10



| | Symptoms | Processing |
|--------------|----------------------------------|---------------------------|
| The or cl | drain plug does not open ose. | Please call for a repair. |

11

(1)





Fix the bathtub



(7) \bigcirc Required Fix the bathtub in place with mortar using the provided sleeves (A-7).

Finishing





2019. 1 Printed in China NTE237