



1. MAIN KEYS

- +

Adjusts the WASHLET's water pressure



Starts bidet cleansing, press again to activate forward and backward -Oscillating- motion



Starts rear cleansing, press again to activate forward and backward -Oscillating- motion



Adjusts the water flow position



Stops washing

2. SUB KEYS



Selects and displays the WASHLET's water temperature



Adjusts the WASHLET's water and seat temperature



Purifies the air inside the bowl through a powerful filter



Selects and displays the WASHLET's seat temperature